

Assembly of our UNSPLASH M02 on your fork

Downhill | Enduro | Trail | All Mountain | Marathon | XC | 20"-29"

1. Please open the packaging at the point shown below.



Assembly of our UNSPLASH M02 on your fork

Downhill | Enduro | Trail | All Mountain | Marathon | XC | 20"-29"

2. Remove the UNSPLASH M02 and the enclosed cable ties from the packaging.



Assembly of our UNSPLASH M02 on your fork

Downhill | Enduro | Trail | All Mountain | Marathon | XC | 20"-29"

3. Pull the shrink tubes over the cable ties and insert the cable ties into the openings as shown. The longer cable ties need to be inserted at the side wings.



Assembly of our UNSPLASH M02 on your fork

Downhill | Enduro | Trail | All Mountain | Marathon | XC | 20"-29"

4. Tighten the cable ties, first the upper ones and then the side ones. Finally, remove the ends. That's it! **Unleash yourself!**

